



### **ADJUSTABLE ROLL-OUT KIT INSTALLATION INSTRUCTIONS**

**COMPONENTS:**

- (4) Pilasters                      11/16" x 1-1/8" x 16"
- (4) Drawer Rails                11/16" x 1-1/8" x 21-25/32"

**IMPORTANT!**

Internal cabinet width must be at least 1-1/2" wider than inside width of face frame. Distance between front pilasters should not exceed tray dimensions by more than 1-1/16".

- Step 1:            Install pilasters in each front corner with rabbeted edge facing the inside corner and notches facing rear of cabinet. Fasten to face frame with #6 x 1-1/2" screws.
  
- Step 2:            Install pilaster in each rear corner with rabbeted edge facing back panel and notches facing the side panel. Fasten with #6 x 1-1/4" screw.
  
- Step 3:            Measure depth of cabinet and, if necessary, cut drawer rail (on non-notched end) to length.
  
- Step 4:            Attach cabinet member of drawer slide to the 11/16" x 21-1/16" edge of drawer rail with the notched end as the rear edge.
  
- Step 5:            Insert notched end into rear pilaster and slide rail into front pilaster.