

RV-8PB Adapter Kit



Instruction for Installation

Use four #6 x 5/16" flat head screws and nylon nuts to mount product member to slide instead of four #70 x 1/2" screws and nuts (included in door mount kit).

Follow all other instructions in RV DM KIT.

If using spacers, angle brackets can be spaced out, but space will not allow spacing inside of product member.