

PLEASE READ ALL INSTRUCTIONS BEFORE INSTALLING YOUR MEDICINE CABINET. FAILING TO DO SO MAY RESULT IN AN IMPROPER INSTALLATION AND VOID THE WARRANTY.

Note #1 **The best method for surface mounting a cabinet is to place horizontal blocking between the studs when framing. This creates a solid backing for WAVE *Steel Bracket Screws*. The proper placement of blocking is centered at 3" and 32" lower than the anticipated line position in step #2 (below). Alternatively, *Heavy Duty Hollow Wall Toggle Bolts* or *Drywall Toggle Bolts* (not included) can be used to secure WAVE *Mounting Brackets* in standard sheet rocked walls.**

Note #2 **WAVE medicine cabinets are best installed by first removing the door(s). If you choose to install a cabinet with its door(s) on, two people are absolutely required.**

After removing your cabinet from its shipping carton, verify that there is no damage and that the following parts were received:

Single & Double Cabinets

- (1) Aluminum Rear Panel**
- (3) Glass Shelves**
- (12) Plastic Shelf Supports**
- (2) Mounting Brackets**
- (4) Steel Bracket Screws**
- (4) Plastic Screw Anchors**
- (1) Plastic Filler Strip**

Triview Cabinets

- (2) Aluminum Rear Panel**
- (6) Glass Shelves**
- (24) Plastic Shelf Supports**
- (4) Mounting Brackets**
- (8) Steel Bracket Screws**
- (8) Plastic Screw Anchor**
- (2) Plastic Filler Strip**

Fig. 1

The following tools are needed for all installations:

Power Drill, #2 Phillips Screwdriver / Screw Bits, Tape Measure, Level, Pencil, and Drill Bits

SINGLE & DOUBLE DOOR CABINETS

SURFACE MOUNTING YOUR MEDICINE CABINET

1. Detach doors by placing the medicine cabinet flat on its back. Open and firmly hold each door. Lift the lever (at the back of each hinge) to disengage each door. Please do not force the release. Leave plastic corner guards on the doors until the installation is complete. Remove parts from the interior.
2. Mark your wall at the desired overall height of the back of the aluminum box – NOT the front flange top.
3. Draw a level horizontal line 2" below the overall height, and place a vertical mark on this line (where the cabinet will be centered).
4. Align the top edge of one **Mounting Bracket** with the above horizontal level line.
5. Fasten **Steel Bracket Screws** into studs/blocking (if used). If none exist, use toggle bolts, etc. (not included) to fasten the *Mounting Bracket*.
6. Level and secure the *Mounting Bracket*.

7. Slide the aluminum box onto the top *Mounting Bracket*.
8. Place the second **Mounting Bracket** on the top edge of the bottom aluminum extrusion.
9. Repeat step #5 for the bottom *Mounting Bracket*.
10. Ensure that the aluminum box is level and secure on your wall.
11. Drop the **Plastic Filler Strip** into the slot in front of the lower *Mounting Bracket*.
12. Lift the **Aluminum Rear Panel** into the upper rear extrusion slot and then seat it into the bottom slot.
13. Install the **Plastic Shelf Supports** and **Glass Shelves** at desired positions.
14. Re-attach the mirrored door(s) onto the aluminum box and remove any plastic corner guards.

RECESS MOUNTING YOUR MEDICINE CABINET*

1. Detach door(s) by placing the medicine cabinet flat on its back. Open and firmly hold each door. Lift the lever (at the back of each hinge) to disengage each door. Leave plastic corner guards on the doors until the installation is complete. Remove parts from the interior of the aluminum box.
2. If necessary, drill four (4) 1/4" holes in cabinet sides – one hole 3" above or below the inside corners.
3. Place the aluminum box into a proper rough opening for the cabinet. Plumb and square.
4. Screw the cabinet snug to the studs, ensuring that the aluminum box is level.
5. Drop the **Plastic Filler Strip** into the lower extrusion slot.
6. Lift the **Aluminum Rear Panel** into the upper extrusion slot and then seat it into the bottom slot.
7. Install the **Plastic Shelf Supports** and **Glass Shelves**.
8. Re-attach the mirrored door(s) onto the aluminum box and remove plastic corner guards.

Fig. 1

TRIVIEW CABINETS

The procedure for surface mounting a WAVE Triview medicine cabinet is nearly identical to that of a WAVE single or double door cabinet. Recess mounting a Triview cabinet box is also a similar procedure. Please refer to the respective procedures above for general reference.

The procedure differs in that WAVE Triview medicine cabinets have two compartments – one large; one small. Because of this, completing various aspects of surface mounting is doubled – there are twice the number of **Mounting Brackets**, **Plastic Filler Strips** and **Aluminum Rear Panels**, etc. Care must be taken in positioning the two upper *Mounting Brackets* to accurately center a Triview cabinet. To do this, place the aluminum box on your wall at its final position and trace a pencil line inside of the top of both rear openings. Center each *Mounting Bracket* horizontally on these lines and secure each with its top edge 1/4" above those pencil lines. Continue with step #7 of the "Surface Mounting Your Medicine Cabinet" section doubling the procedure where applicable.

MIRRORED SIDE KITS

Once your surface mounted cabinet is in place and secure, carefully apply one of the mirrored sides to each side of the cabinet. Take care to properly position each piece into place.