

INSTALLATION INSTRUCTIONS



- 1) LAY OUT YOUR PARTS: (A) THE SHELF ITSELF (B) THE PAIR OF GUIDES (C) **ONESCREW BAG**, PER ORDER. **FOUR** SCREWS PER SHELF.
- 2) PLACE THE GUIDES ONTO THE LOCATION WHERE THEY ARE TO BE INSTALLED. MAKE SURE THE ROLLERS ARE FACING IN AND TOWARD THE FRONT OF THE SHELF. (THE METAL “L” BRACKETS WELDED ON THE GUIDE SHOULD FACE DOWN TOWARD THE MOUNTING SURFACE). SEE THE PHOTO ABOVE. YOU WILL HAVE 1 LEFT GUIDE & 1 RIGHT GUIDE PER SHELF. R OR L SIDE IS DETERMINED BY FACING THE FRONT OF THE SHELF.
- 3) PLACE THE SHELF INTO YOUR CABINET.
- 4) CLOSE YOUR CABINET DOOR, MAKING SURE YOU HAVE THE PROPER CLEARANCE TO INSTALL YOUR NEW ROLLINGSHELF.
- 5) ONCE YOU ARE SURE THE SHELF WILL FIT PROPERLY; FIT THE SHELF ONTO THE GUIDES THAT YOU PLACED INSIDE THE CABINET. ROLL OUT THE SHELF FAR ENOUGH TO SEE THE “L” BRACKET IN THE REAR. MAKE A MARK THROUGH **ONE** OF THE HOLES IN BOTH THE LEFT AND RIGHT REAR “L” BRACKET. THIS MARK IS WHERE YOU WILL PLACE A SCREW TO HOLD THE BACK OF THE GUIDE. MAKE SURE YOUR NEW SHELF IS STRAIGHT BEFORE MAKING THE MARKS OR INSTALLING ANY SCREWS. REPEAT PROCEDURE FOR THE FRONT “L” BRACKETS.
- 6) FASTEN THE GUIDES INTO THE CABINET, USING THE INCLUDED SCREWS. INSTALL 1 SCREW THROUGH THE BRACKET USING THE MARK YOU MADE AS A GUIDE. AT THIS POINT DO NOT FULLY TIGHTEN THE SCREWS.
- 7) MAKE SURE THE GUIDES ARE PARALLEL TO EACH OTHER. THIS WILL ASSURE A SMOOTH GLIDING SHELF.
- 8) INSTALL THE ROLLINGSHELF AND SLIDE IT FORWARD AND BACKWARD, ADJUSTING THE SCREWS AS NEEDED. ONCE YOU HAVE A SMOOTH FIT, TIGHTEN THE SCREWS TO SECURE.

THESE ROLLINGSHELVES, ARE DESIGNED TO FIT ON AN EXISTING CABINET SHELF OR FIXED BASE.

OTHER INSTALLATION OPTIONS ARE AVAILABLE.

CONTACT US TO FIND OUT MORE INFORMATION.