

FUJIOH KITCHEN VENTILATING
APPLIANCE
INSTALLATION INSTRUCTIONS FOR
WOOD HOOD AND POWER UNIT

LINER

1. Scribe a line (B) distance from top of adjacent cabinets. Position wood filler blocks flat on side of adjacent cabinets above scribe lines between frame stiles and rear wall and securely fasten to cabinets.
2. Position liner so that bottom edge is level with scribed lines and drive #8 screws through holes in the liner. Screw length should be such that firm attachment through blocks and into cabinet is accomplished. Repeat on other side.
3. If possible, locate wall studs, drill holes through back of liner and attach to wall securely.
4. Metal liner should also be fastened to skirt of hood after it is hung into place.

Ventilator Power Unit

1. Make sure electrical power is turned off at fuse box. Start duct run and electrical cable from soffit or wall.
2. Remove aluminum mesh filter.
3. Remove the front panel (four screws)
4. With the four mounting screws (in packet) mount Fujioh ventilator so that the four screws go thru holes in the Fujioh Ventilator unit and the liner. Attach four nuts provided, securing tightly.
5. Connect duct run to damper collar. Seal all joints with furnace tape to prevent air leaks and rattles. Be sure damper shutter, if used, is operating freely.
6. Run power supply cable into Fujioh ventilator compartment through knock out, secure with cable connector nuts (not furnished).
7. Connect power line to black leads, power line 2(ground) to white leads with wire nuts (not furnished). Replace wiring compartment cover.
8. Insert light bulb into lamp receptacle,
9. Reinstall blower front panel by

attaching it to the four weld studs using four screws (removed in step3).

10. Reinstall the aluminum mesh filter.

WOOD HOOD

1. Slide wood hood into opening between wall cabinets over metal liner. Wood frame on front of hood should be flush with frames of adjoining cabinets.
2. Drill top and bottom holes through the front frames of the adjoining wall cabinets. Drive #6x2 1/2" screws through holes into wood hood fastening it into place. Drive three #8x3/8" screws through front of metal liner into back of wood hood front to attach liner securely.

Your Fujioh ventilation system is now ready for operation. Turn electrical current back on and follow procedures as outlined in the unit's operation manual.

Your installation is now complete.