


Old Dutch

Series #106

an **EefaCo.** Store
1-877-275-9111

60" Ht. 6 Shelf Cookware Stand



We have included these instructions to make assembling your Cookware Stand as simple as possible. Familiarizing yourself with the parts and reading through these instructions carefully before assembly will help make putting together your Cookware Stand easy and fast. The only tool needed for assembly is a screwdriver, although a socket wrench or pliers may be helpful.

Assembly Instructions

1. Unwrap all parts. Sort out the shelf members into 6 sets of 3 shelf members each of equal size (from "A" to "F", largest to smallest).
2. Locate the 3 lower stand uprights (these will have flat feet on one end) and shelf member set "C". Using only the bottom row of holes on each shelf member, attach shelf members "C" to the lower stand uprights. Use 2 sets of screws and nuts for each joint and hand-tighten. Take care to keep all screw and nut sets going in the same direction.
3. Locate the 3 upper stand uprights (these will have scrolls on one end). Attach to shelf members "C", using 2 sets of screws and nuts for each joint. Take care to keep all screw and nut sets going in the same direction. Tighten all screw/nut sets.
4. Attach shelf members "A", "B", "D", "E" & "F" to the upper & lower stand uprights, using one screw/nut set at each joint. Take care to keep all screw and nut sets going in the same direction. Hand-tighten only.
5. Square up the stand so that the feet sit flat upon floor and all shelves are straight. Tighten all screws and nuts.

Care and Use

Decor Copper Finish: The copper plating has been given a clear, protective coating to prevent tarnishing. Clean with a soft, damp cloth. You can also use a window cleaner. Dry thoroughly. Never use abrasive cleaners.

Chrome Finish: Clean with a soft, damp cloth. You may also use a window cleaner. Dry thoroughly. Never use abrasive cleaners.

Powder Coat Finish: Clean with a sponge, moistened with dish-washing solution. Dry thoroughly. Never use abrasive cleaners.

Warning: It is important that your Cookware Stand is properly assembled. If the rack is incorrectly assembled it could become unstable or collapse, possibly causing damage or injury.

This stand is intended to be placed out of the way of foot traffic, where it will not be bumped or leaned on. It is not intended to protect stored items from spilling, and the rack itself can be tipped over if not placed and used carefully. Improper use or placement could cause the rack and/or its contents to fall or spill, possibly causing damage or injury. This stand should always be positioned against a wall, in a corner or otherwise placed where it will not be bumped into or leaned upon.