


# Arts & Crafts Dining Table

## IMPORTANT NOTE

Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occurring to the wood parts.


We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.




*Home  
Styles.*

Casual Attire For Today's Home


## Part List




A.  
Top  
1 pc.



B.  
Top  
1 pc.



C.  
Leaf  
1 pc.




D.  
Table Slide  
2 pcs.



E.  
Leg  
4 pcs.

## Hardware List



Key Wrench  
1 pc.



Hex Wrench  
1 pc.



Wood Screw  
16 pcs. (+1 extra)



Spring Washer (Small)  
8 pcs. (+1 extra)



Spring Washer  
8 pcs. (+1 extra)



Flat Washer (Small)  
8 pcs. (+1 extra)



Flat Washer  
8 pcs. (+1 extra)



Head Cap Bolt  
8 pcs. (+1 extra)




Bolt  
8 pcs. (+1 extra)

## IMPORTANT

\*Do not tighten up all the screws until each part is properly assembled.

\*You should keep Hex Wrench, Key Wrench in a safe place as you may need to tighten up the Bolts in the future.





## STEP 1

Place Top (A) and (B) face side down on a soft cloth.

Remove Table Slides (D) from their packing position by loosening and removing Head Cap Bolts, Spring Washers(Small) and Flat Washers(Small) using Hex Wrench.(see Figure 1)

**Note:** These 4 Head Cap Bolts, Spring Washers(Small) and Flat Washers(Small) will be used in Step 2.

**DO NOT DISCARD**





## STEP 2

Attach Top (A) with (B), by aligning dowels with the holes and firmly pushing together.

Engage the locks by turning their handles clockwise  $\frac{1}{4}$  turn (see Figure 2).

Attach Table Slides (D) to the unit using Head Cap Bolts, Spring Washers(Small) and Flat Washers(Small). Tighten Wood Screws (see Figure 3).





## STEP 3

Attach Legs (E) to the unit with Flat Washers, Spring Washers and Bolts see Figure 3.  
Turn the table over to its' upright position.





Figure 3

## Adding the Leaf



## STEP 4

Disengage the locks by turning their handles counter-clockwise  $\frac{1}{4}$  turn (see Figure 4).

Pull out both sides of the table, then place Leaf (C) in the unit as shown, aligning the dowels with the holes.




Figure 4

Push the table together firmly, then engage the locks by turning their handles clockwise  $\frac{1}{4}$  turn (see Figure 2).

# VERY IMPORTANT !!

## CARING INSTRUCTIONS

### NEVER

USE GLASS CLEANERS ON FINISHED FURNITURE. AMMONIA WILL CHEMICALLY ATTACK THE LACQUER.

### NEVER

ALLOW LIQUIDS OF ANY KIND TO REMAIN IN DECORATIVE ROUTE LINES. ABSORPTION CAUSES WOOD TO WARP AND FINISH TO DE-LAMINATE.

DO NOT  
WRITE  
DIRECTLY  
ON  
SURFACE.



**PREVENT  
MARKING**

DO NOT  
PLACE IN  
DIRECT  
SUNLIGHT.



**PREVENT  
FADING**

DO NOT USE  
COMMERCIAL  
WAXES AND  
POLISHES.



**PREVENT  
YELLOWING**

DO NOT  
PLACE HOT  
KETTLES  
POTS, ETC  
ON SURFACE.



**PREVENT  
DAMAGE TO FINISH!**

DO NOT  
USE  
RUBBER-  
BASED  
PLACEMATS  
USE CLOTHS!



**PREVENT  
DISCOLORING**

## TO CLEAN

SIMPLY USE A SOFT CLOTH MOISTENED IN LEMON OIL POLISH OR LUKEWARM SOAP & WATER THEN BUFF WITH A DRY CLEAN CLOTH!

